

## WIRELESS DOOR SENSOR (ISG-TWS) INSTALLATION GUIDE

THIS SENSOR NEEDS A ISMARTGATE-PRO AND/OR ISMARTGATE-LITE DEVICE TO WORK.

### Read instructions carefully before beginning

Please make sure your garage door is closed before you start installation.

The ismartgate product and our wireless door sensors are meant to be used with garage door openers equipped with photo-eye safety sensors (manufactured after 1993). These sensors are normally found at the bottom of your garage door and avoid accidental closing of your garage door if an object or person is on the path of the door.



### TO PREVENT SERIOUS INJURY OR DEATH FROM MOVING GARAGE DOORS OR GATES:

- DO NOT let children use the ismartgate product and app without adult supervision.
- ONLY Operate your ismartgate device when you are in clear view of your garage or gate and you have verified that there are no objects obstructing the operation of the door. ALWAYS wait for garage door or gate to be completely closed.
- NEVER operate the remote access feature of your ismartgate without ensuring that there is an adult physically present in front of the door or gate validating that it is safe to start the remote operation of your device

1

Unscrew the 4 screws and place the batteries as per picture.



3

If you install the wireless sensor for the first time, follow the ismartgate app instructions.

If you are replacing it, go to **ismartgate app > Settings > Doors**

SPECS	GGG2-TWS-001
Frequency	2.4 Ghz
Range	50 m or 150 ft (open space)
Operating Temperature	-10°C to 70°C
Battery type	N (x2)
Battery life span	2 years
Packaging	Clamshell
Certification	CE - FCC




### Main sensor's features:

- Remotely monitor if garage door is open or closed
- Check garage door temperature in °C/°F
- Receive real time alerts on your Smartphone
- Easy to install tilt sensor with double sided tapes
- Accelerometer to detect open/close position
- Monitor sensor's battery status for prompt replacement
- Keep track of all garage door events in a built-in calendar of events

### Still having issues. No problem.

Download our user manual in our website [www.ismartgate.com](http://www.ismartgate.com) or contact us at: [support@ismartgate.com](mailto:support@ismartgate.com)


2



Always install your wireless door sensors with the garage doors in a closed position. Put the provided 2x Type N batteries into the sensor.

Make sure you place the sensor with the "TOP" label facing the garage door ceiling.

Attach your wireless sensors to your garage door as per drawing below.



Place the sensors on the upper part of your garage door wall.

### Modification statement

Remsol Europe has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment.

### Interference statement (if it is not placed in the device)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### Wireless notice

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

### FCC Class B digital device notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.